


VBO 2: 100 x 176 mm



C Ø 10 mm

D 92 x 168 mm



truma Boiler/Ultrastore

(D) Baureihe 2 + 3

1. Schablone an der Wand-Innenseite anlegen.

- A = Unterkante Boiler
B = Seitenkante Boiler
C = 4 Löcher Ø 10 mm durch die Wand bohren.
E = Loch Ø 15 mm für Kondenswasserrohr bohren
(auch von außen möglich = F).

2. Schablone an der Wand-Außenseite anlegen.

- C = Markierungen müssen über den Durchbohrungen liegen.
D = Kaminausschnitt 92 x 168 mm aussägen.
Bei Einbau mit Kaminverlängerung VBO 2 nach gestrichelter Linie aussägen.
F = Loch Ø 15 mm für Kondenswasserrohr bohren.

(GB) Line 2 + 3

1. Put the template against the inside of the side wall.

- A = Lower surface of the water heater
B = Lateral edge of the water heater
C = Drill 4 10 mm Ø holes through the wall.
E = Drill a 15 mm Ø hole for the condensate tube
(is also possible from the outside = F).

2. Put the template against the outside of the side wall.

- C = Markings must be over the bore holes.
D = Saw out the hole for the cowl of 92 x 168 mm.
If a cowl extension VBO 2 is fitted, saw out a hole of 100 x 176 mm according to the broken line.
F = Drill a 15 mm Ø hole for the condensate tube.



E Ø 15 mm

F Ø 15 mm

